

**BACTERICIDE**  
**FUNGICIDE**  
**ALGICIDE**

## SE-4210 **STERILE** ANTIMICROBIAL PRESERVATIVE

*Sterile anti-microbial preservative to be used with portable eyewashes such as the Speakman SE-4000 Gravityflo and SE-590 Portable Eyewashes. Item is packaged with four - 8 fl.oz bottles and each bottle is sufficient to treat 5 - 21 gallons of water for a period of up to 180 days.*

Contents: Chlorohexidine Gluconate

### DIRECTIONS

DO NOT USE IF SEAL IS BROKEN OR MISSING

1. Clean station
2. Rinse with Potable Water
3. Partially fill station with Potable Water
4. Add entire contents of bottle
5. Fill station to mark
6. Date inspection tag
7. Change solution every 180 days, minimum

### TESTING:

Activate unit weekly to insure proper flow. Testing, based upon 15 seconds will use about 592 ml (20 oz) of solution per test. Replace it with clean Potable water after each test. Additive is formulated to accept this new Potable Water weekly for a six-month period. Date inspection tag. Use only as directed. In case of contact with eyes, flush eyes with Potable Water.

*Meets requirements of Anti-microbial Preservatives Effectiveness Test method USP 23*



# SPEAKMAN®

P.O. Box 191 Wilmington, DE 19899  
Phone: 1-800-537-2107 Fax: 1-800-977-2747  
[www.speakmancompany.com](http://www.speakmancompany.com)